STEP 1

381-000004

PLEASE FOLLOW INSTRUCTION LISTED BELOW IN THE PROPER SEQUENCE AS NUMBERED TO ASSURE FAST, EASY AND CORRECT ASSEMBLY

| 1 22,021 022011 11011 001101 | | |
|------------------------------|-------------------------|-------|
| HARDWARE LIST | | |
| NO | DESCRIPTION | QTY |
| Α | M6 X 25mm JCBC SCREW | 4 PCS |
| В | M6 X 50mm JCBC SCREW | 8 PCS |
| С | SPRING WASHER | 8 PCS |
| D | M8 X 35MM WOOD DOWEL | 1 PC |
| Ε | M4 X 30MM CSK SCREW | 8 PCS |
| F | M4 ALLEN KEY | 1 PC |
| PART LIST | | |
| NO | DESCRIPTION | QTY |
| 1 | FRONT RAIL | 1 PC |
| 2 | BACK RAIL | 1 PC |
| 3 | LEG (L&R) | 1 SET |
| 4 | CUSHION SEAT | 1PC |
| 5 | BACK CUSHION | 1 PC |
| 6 | STRETCHER | 2PCS |
| | | |

FULL SETUP





