








110-000110


Assembly instructions



A	B	C	D	E
				
x 1	x 1	x 1	x 1	x 1




F




x 4

G



x 6

H




x 2

I



x 12

J



x 6

K




x 6

L




x 2

M



x 1

N




x 1

O




x 4

P





x 6

!






1




A	E	K	J	G	P	M
x 1	x 1	x 2	x 2	x 2	x 2	x 1






2




3




4




!



5

F  x 4	I  M6 x 20 x 12	N  x 1	O  x 4
---	--	---	---



6

B  x 1

