




























184-000126



2x  S3	6x  Ø 3,5x25mm E1
2x  E8	1x  R
8x  Ø 3.5x16 mm E3	12x  Ø 6,4x50mm B1
4x  P	12x  B

Nº	a x b	x
1	800x280	1
2	764x270	1
3	196x764	1
4	384x279	2
5		





Important information
Read carefully.
Keep this information for further reference.

(GB) WARNING

Serious or fatal crushing injuries can occur from furniture tip-over. To prevent this furniture from tipping over it must be permanently fixed to the wall.

Fixing devices for the wall are not included since different wall materials require different types of fixing devices. Use fixing devices suitable for the walls in your home. For advice on suitable fixing systems, contact your local specialized dealer.