

ASSEMBLY INSTRUCTIONS

GRIDEA PAKOWORLD BOOKCASE SONOMA


383-000128




IMPORTANT


PLEASE READ BEFORE YOU CONTINUE FURTHER

1. MATERIAL USE LAMINATED PARTICLE BOARD, TO CLEAN USE SOFT, DRY CLOTH.
2. DO NOT USE DETERGENT OR CHEMICAL AVOID CONTACT WITH WATER AND DIRECT SUNLIGHT.
3. TO BE ASSEMBLED ON A SOFT, DRY, CLEAN SMOOTH SURFACE.
4. DO NOT USE ANY TOOLS OTHER THAN THOSE SHOWN.
5. USE OF POWER TOOLS TO ASSEMBLE THIS PRODUCT WILL INVALIDATE ANY CLAIM AND MAY DAMAGE THIS PRODUCT MAKING IT UNSAFE.
6. BEFORE STARTING ASSEMBLY PLEASE VERIFY IF ALL PARTS AND HARDWARE ARE INCLUDED.

HARDWARE LIST			QTY (pcs)
DW4		Wood Dowel 6 x 25mm	44
LG1		Leg Pin	8
MF2		Nail	40 (+ -3)
PF11		Small L Bracket	2
SC3		Screw M3.5 x 14mm	4
SC18		Screw M4 x 38mm	20




Parts List		QTY
A	Side Panel (L)	1 pc
B	Side Panel (R)	1 pc
C	Center Panel	6 pcs
D	Top Panel	1 pc
E	Shelf Panel	2 pcs
F	Bottom Panel	1 pc
G	Crossbar Panel	2 pcs
H	Backboard	6 pcs




STEP 1


DW4		Wood Dowel 6 x 25mm	44
-----	--	------------------------	----




STEP 2



STEP 3




STEP 4



STEP 5

MF2		Nail	40 (+/-3)
-----	---	------	--------------



STEP 6

LG1		Leg Pin	8
PF11		Small L Bracket	2
SC3		Screw M3.5mm x 14mm	4

